

CFL BULB PAK DIRECTIONS

- Step 1** - Square up box & fold in Bottom flaps
- Step 2** - Tape Bottom flaps with 2" wide poly packaging tape with two strips in a cross pattern
- Step 3** - Insert Poly bag
- Step 4** - When full, close poly bag with zip-tie provided
- Step 5** - Close Top flaps & tape with 2" wide poly packaging tape with two strips in a cross pattern

GLASS

HANDLE WITH CARE

DO NOT CRUSH

FRAGILE

DO NOT DROP

1-800-282-4293
www.cleanearthsystems.com

