



15245 Amberly Drive  
Tampa, FL 33647  
[www.cleanearthsystems.com](http://www.cleanearthsystems.com)

Toll Free: (800) 282-4293  
Fax: (813) 930-2530

## GREEN DRUM Set-Up & Closure Instructions

---

### DIRECTIONS

**STEP 1:** Insert poly liner

**STEP 2:** When full, cinch poly liner closed with 11" zip-tie provided.

**STEP 3:** Place cap on drum and secure with steel locking band provided in area indicated on cap.

