

HSC Haz Box Closure Instructions

- 1. Square up box
- 2. Nail bottom flap A into top deck boards with 6 nails.
- 3. Fold in bottom flaps B & C.
- 4. Fold in flap D & position box in upright position.
- 5. Insert poly liner.
- 6. When full, cinch liner & twist.
- 7. Secure liner closed with 2" 3M #375 packing tape or HyStik #970 (3") clear filament tape (min. 12" long)
- 8. Place Lid on the Top of the Box
- 9. Secure Box & Lid to pallet by placing (2) 1/2" plastic straps in area designated on the lid.
- 10. Tighten plastic straps to fullest extent using plastic strap hand closure tool.